


KitchenAid®

CABINET PARTS

For Model: KSSC48FMS03
(Stainless Steel)

48" BUILT IN
REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: KSSC48FMS03


(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------------------------------|------------|----------|------------------------------------|------------|----------|----------------------------------|
| 1 | | Literature Parts | 11 | 2005783 | Cam, Door Closer | 31 | 8533913 | Screw 1/4–20 x 5/8 |
| | 2320531 | Use & Care Guide | 12 | 2209022 | Housing, Water Filter | 32 | 2209026B | Skirt–Grille, Bottom |
| | 2307364 | Energy Label | 14 | 3400525 | Screw | 33 | | Extension Arm, Door Closer |
| | 2320619 | Service & Wiring Sheet | 15 | 2255709 | Filter, Water | | 2266882 | Right |
| | 2306337 | Icemaker and Ingredient Care Center | 16 | 489399 | Screw | | 2266881 | Left |
| | | Service Sheet | 17 | 3400230 | Screw, Door Stop | 34 | 2209431B | Grille Bottom, Front |
| | 2302865 | Main Control Service Sheet | 18 | 2257644 | Hinge (Top) | 35 | 2005921 | Screw |
| | 2309069 | Installation Instructions | 19 | 2307582 | Bracket, Mtg (Water Filter) | 36 | | Bracket, Support Base (Front) |
| 2 | | Cabinet (Not A Serviceable Part) | 20 | 489464 | Screw | | 2006616 | Left |
| 3 | 2320650 | Clamp, Tube | 21 | 2004994 | Lock, Adjustable Bushing | | 2006556 | Right |
| 4 | 1112023 | Roller, Front & Rear (4) | 22 | 2300082 | Bushing | 37 | 1157158 | Screw |
| 5 | | Support, Leveler Assembly | 23 | 2209090 | Clamp, Filter Housing | 38 | 2006617 | Bracket, Support Base (Rear) (2) |
| | 2004506 | Refrigerator Side | 24 | | Spring, Door Closure | 39 | 2006346 | Washer |
| | 2004505 | Freezer Side | | 2221242 | Right Side | 40 | 2266880 | Bushing, Extension Arm |
| 6 | 2005006 | Grommet, Wiring | | 2004517 | Left Side | 41 | 1163283 | Screw |
| 7 | 2005007 | Grommet, Flexible | 25 | 486194 | Screw | 44 | | Switch, Rocker Arm |
| 8 | | Cap, Water Filter | 26 | 2005008 | Retaining Ring, Adjustable Bushing | | 1118894 | Refrigerator Door Side |
| | 2186494B | Black | 27 | 2320677 | Wire Clip (5) | | 1115373 | Freezer Door Side |
| 9 | 2006442 | Mounting Stud, Grill | 28 | 2006342 | Gap, Cover Assembly (Bottom) | 45 | 2215938 | Cover, Switch (2) |
| 10 | 2005004 | Grommet, Crossover Tube | 29 | | Hinge (Bottom) | 46 | 487415 | Screw (2) |
| | | | | 2006780 | Freezer Side | 47 | | Bracket, Switch |
| | | | | 2006779 | Refrigerator Side | | 2221097 | Right |
| | | | 30 | 2302876 | Bushing, Adjustable | | 2221096 | Left |
| | | | | | | 48 | 2215612 | Cover, Rear |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Model: KSSC48FMS03
(Stainless Steel)




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|----------------------------|
| 1 | 2222552S | Cabinet, Trim (Right Side) |
| 3 | 1163283 | Screw |
| 4 | 2316688 | Cabinet, Trim (Bottom) |
| 5 | 486194 | Screw |
| 6 | 2313993 | Cabinet, Trim Top |
| 7 | 2222553S | Cabinet Trim (Left Side) |
| 9 | 2005925 | Seal-Trim, Side |
| 10 | 489464 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: KSSC48FMS03
(Stainless Steel)




| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|------------------|
| 1 | 2302869 | Wire, Shelf |
| 2 | 2302872 | Cover, Shelf |
| 3 | 2302884 | Shelf, Fixed |
| 4 | 2259086 | Gasket |
| 5 | 2256271 | Front, Basket |
| 6 | | Slide, Basket |
| | 2259317 | Right Side |
| | 2259318 | Left Side |
| 7 | 8533928 | Screw |
| 8 | 2266935 | Door, Ice |
| 9 | 2266932 | Bucket, Ice |
| 10 | 2266955 | Spacer, Ice Door |
| 11 | 8533929 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: KSSC48FMS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Model: KSSC48FMS03
(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--------------------------------|
| 1 | | Liner (Not A Serviceable Part) |
| 3 | 2208970 | Air Duct |
| 4 | 2209204 | Clip, Thermistor |
| 5 | 2259077 | Ladder, Shelf (2) |
| 6 | 520965 | Screw Support, Ladder (8) |
| 7 | 2006475 | Screw |
| 8 | 487539 | Screw |
| 9 | 2302937 | Thermistor |
| 10 | 2302986 | Lid, Meat Pan Baffle |
| 11 | 2320635 | Baffle Control Assembly |
| 12 | 2171846 | Release Valve |
| 13 | 2310205 | Jumper, Air Baffle |
| 14 | 488357 | Screw |
| 15 | 486194 | Screw |
| 16 | 2306010 | Thermistor |
| 17 | 2221296 | Air Baffle Assembly |
| 21 | 2309222 | Diffuser Assembly |
| 22 | 2317105 | Cover, Thermistor |
| 23 | 2188820 | Thermistor |
| 24 | 2302992 | Spacer, Air-Baffle |
| 25 | 2309087 | Cover, Diffuser |
| 27 | 2259412 | Seal, Air Duct (Round Hole) |
| 28 | 2259398 | Seal, Air Duct (Square Hole) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: KSSC48FMS03
(Stainless Steel)




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------------------------------|
| 1 | 2302773 | Control Box |
| 2 | 2303938 | Insert, Control Box |
| 3 | 2302913 | Circuit Board, Housing Control Box |
| 4 | 2310197 | Control Box Wire Harness |
| 6 | 2221121 | Support, Control Box |
| 7 | 489006 | Screw (2) |
| 8 | 2306086 | Display Board, Ingredient Care Center |
| 11 | 2162085 | Socket, Light |
| 12 | 2255743 | Light Bulb (2) |
| 13 | 486194 | Screw |
| 14 | 8281185 | Screw |
| 15 | 2257520 | Overlay |
| 16 | 2302716 | Shield, Light |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: KSSC48FMS03
(Stainless Steel)




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------------------------------|
| 1 | 2257412S | Panel, Decorative Assembly |
| 2 | 2259320 | Cover, Unit |
| 3 | 486194 | Screw |
| 4 | 2256466 | Back Panel |
| 5 | 2320678 | Cover, Unit Front |
| 6 | 487415 | Screw |
| 7 | 2310194 | Wire Assembly RC/FC Light Switch |
| 8 | 2005292 | Badge, Kitchen Aid |
| 9 | 489348 | Clamp |
| 10 | 2004333 | Nut |
| 11 | 2254759 | Bracket, Louver |
| 12 | 2254762S | Grille, Louver |
| 13 | 488879 | Screw |
| 14 | 2215910 | Grommet, Flexible |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: KSSC48FMS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS


For Model: KSSC48FMS03
(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|---------------------------------|
| 1 | 2222593 | Shelf Assembly |
| 5 | 2179404 | Rack, Wine |
| 6 | 2221071 | Egg Bin |
| 9 | 2302843 | Meat Pan Cover Assembly |
| 10 | 2302836 | Crisper Cover Assembly |
| 13 | 2257583 | Trim, Glass Rear |
| 14 | 2252413 | Crisper Pan (2) |
| 17 | | Slide, Meat Pan |
| | 2302954 | Left Side |
| | 2302955 | Right Side |
| 18 | 2312831 | Trim, Glass Front |
| 19 | 2256255 | Trim, Glass Rear |
| 21 | 2256249 | Front, Crisper Pan |
| 23 | 2252255 | Trim, Glass Side Crisper Pan |
| 24 | 2256250 | Trim, Glass Side Meat Pan |
| 25 | | Spacer, Crisper |
| | 2256222 | Right Side (2) |
| | 2256223 | Left Side (2) |
| 27 | | Slide, Crisper |
| | 2302957 | Right Side (2) |
| | 2302956 | Left Side (2) |
| 28 | | Spacer, Meat Pan |
| | 2256243 | Left Side |
| | 2256244 | Right Side |
| 29 | | Screw |
| | 8533929 | Right Side |
| | 8533928 | Left Side |
| 30 | 2256370 | Pan Assembly Meat |
| 31 | 2256367 | Front, Meat Pan |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS

For Model: KSSC48FMS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS


For Model: KSSC48FMS03
(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|---|
| 1 | 2259385 | Fan Motor |
| 2 | 2266801 | Deflector, Air |
| 3 | 2169142 | Fan Blade |
| 4 | 2223733 | Retainer, Fan Motor |
| 5 | 2302817 | Gasket, Cover |
| 6 | 2223986 | Grommet |
| 7 | 486194 | Screw |
| 8 | 2259464 | Wedge, Air Duct |
| 9 | 488500 | Screw, Ground |
| 10 | 2162085 | Socket, Light (2) |
| 11 | 488937 | Clamp, Nylon |
| 12 | 2255743 | Light Bulb |
| 13 | 2302925 | Bracket, Vent Tube |
| 14 | 2182120 | Scroll, Fan |
| 15 | 2259465 | Wedge, Air Duct |
| 16 | 2302924 | Tube, Vent |
| 17 | 2306044 | Air Duct |
| 18 | 2302851 | Support, Air Duct |
| 19 | | Block, Fan Scroll |
| | 2209482 | Right |
| | 2209066 | Left |
| 20 | 2302777 | Seal, Light Socket |
| 21 | | Liner (Not A Serviceable Part) |
| 23 | 2259025 | Cover, Air Outlet |
| 24 | 2259367 | Light Shield |
| 25 | 2314044 | Cover, Evaporator |
| 27 | 8281163 | Screw |
| 28 | 2317828 | Block, Return Air |
| 29 | 2309284 | Deflector, Air Duct |
| 30 | 1112260 | Support, Evaporator |
| 31 | 2196483 | Shelf, Stud (20) |
| 32 | 8281158 | Screw |
| 33 | | Evaporator, Cover Rail |
| | 2221107 | Left Side |
| | 2259355 | Right Side |
| 34 | 2220904 | Gasket (2) Evaporator Cover |
| 37 | 2317088 | Harness, Evap Fan (Includes Item 55) |
| 39 | 2188820 | Thermistor |
| 40 | 2209204 | Clip, Thermistor |
| 41 | 1116793 | Cover, Thermistor |
| 42 | 2006475 | Screw |
| 44 | 2257571 | Bracket, Light |
| 46 | 2259032 | Ladder, Shelf |
| 47 | 2259445 | Support, Screw |
| 55 | 2317087 | Defrost, Bi-Metal |
| 56 | 8281185 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Model: KSSC48FMS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Model: KSSC48FMS03
(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|---|
| 1 | 2252331 | Refrigerator Door Panel (Includes Item #9) |
| 2 | 2258951 | Brace, Door Corner |
| 3 | 2266854 | Hinge Assembly, Top |
| 4 | 2256381 | Spacer-Door, Top |
| 5 | 489282 | Screw |
| 6 | 2302878 | Hinge Assembly, Bottom |
| 7 | 2222797 | Rail, Lid |
| 8 | 2222983 | Gasket, Utility Bin |
| 9 | 2222812 | Door Gasket, Magnetic |
| 10 | 2306157 | Skin, Door |
| 11 | 2005290 | Handle, Door |
| 12 | 2309060 | Spacer, Door (Handle Side) |
| 13 | 2257637 | Door, Spacer Bottom |
| 14 | 488568 | Screw |
| 15 | 8281250 | Screw, 8-15 x .500 Stainless Steel |
| 16 | 2005433 | Spacer, Door Skin Top |
| 17 | 308544 | Screw |
| 18 | 2005030 | Spacer, Door (Hinge Side) |
| 19 | 2004935 | Spacer, Door Bottom |
| 20 | 2005327 | Filler, Door |
| 21 | 2222919 | End Cap Right Side |
| | 2222920 | Left Side |
| 22 | 2306398 | Plate, Door-Handle |
| 25 | 2222923 | Bin, Utility Center |
| 26 | 2222926 | Door, Utility Bin |
| 27 | 2222774 | Door Shelf |
| 28 | 2165792 | Butter Tray |
| 30 | 2222771 | Shelf, Gallon Door |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Model: KSSC48FMS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Model: KSSC48FMS03
(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--|
| 1 | 2252328 | Freezer Door Panel (Includes Insulation) |
| 2 | 2306398 | Plate, Door-Handle |
| 6 | 2302879 | Hinge, Bottom |
| 7 | 489282 | Screw |
| 8 | 2266854 | Hinge, Top |
| 9 | 2256381 | Spacer-Door, Top |
| 14 | 2222810 | Door Gasket, Magnetic |
| 16 | 2005290 | Handle, Door |
| 17 | 2309060 | Spacer, Door-Skin Handle Side |
| 18 | 2257637 | Door, Spacer |
| 19 | 2306161 | Skin, Door |
| 20 | | Screw |
| | 8281250 | Stainless Steel |
| 21 | 2005433 | Spacer, Door-Skin (Top) |
| 22 | 488568 | Screw |
| 23 | 2004933 | Spacer, Door-Skin (Bottom) |
| 24 | 2005030 | Spacer, Door-Skin (Hinge Side) |
| 25 | 308544 | Screw, Handle |
| 26 | 2005323 | Filler, Door |
| 27 | 2258951 | Brace, Door Corner |
| 28 | 2222777 | Bin, Shelf F.C. (6) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: KSSC48FMS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: KSSC48FMS03

(Stainless Steel)


| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---|------------|----------|--------------------------------------|---|-----------------------|----------------------------------|
| 1 | 2304175 | Inverter Box | 21 | 2317982 | Drier | 45 | 2310217 | Wiring Harness, Unit Compartment |
| 2 | 489373 | Screw, Compressor Mounting (4) | 22 | 2310207 | Wire Assembly (Condenser Fan) | Following Parts Not Illustrated and Optional Parts Not Included | | |
| 3 | 2302967 | Compressor (Includes Items 6 & 9)(Also Order 876765 Tube Kit) | 23 | 2206036 | Motor, Fan | | | |
| 4 | 2257354 | Housing, Control Board | 24 | 2190685 | Blade, Fan | 978025 | Valve, Access (1/4") | |
| 5 | 2215641 | Bracket, Fan Motor | 25 | 2003169 | Orifice, Fan | 978026 | Valve, Access (5/16") | |
| 6 | 1100826 | Grommet, Mounting | 26 | 2259302 | Tube, Drier Transition | 978027 | Valve, Access (3/8") | |
| 7 | 2266803 | Shroud, Condenser (Right) | 27 | 8281160 | Screw | 978028 | Valve, Access (1/2") | |
| 8 | 2302969 | Bracket, Switch | 28 | 2259341 | Tube, Heat Loop Transition | 978029 | Valve, Access (5/8") | |
| 9 | 2215676 | Terminal Cover | 29 | 486692 | Speed Nut | 978030 | Valve, Access (3/4") | |
| 10 | 2302973 | Shroud, Condenser (Left) | 30 | 2259349 | Housing, Power Supply | 876764 | Valve, Access (3/16") | |
| 11 | 2307028 | Control Board | 31 | 2259350 | Power Supply, Ingredient Care Center | REFRIGERANT CHARGE | | |
| 12 | 2203075 | Spacer (5) | 32 | 2000645 | Sleeve, Condenser | | | |
| 13 | 2256328 | Bracket, Inverter Box | 34 | 2194319 | Process, Tube | 7.75 oz. (R-134A) | | |
| 14 | 8281149 | Screw | 36 | 2209495 | Cover, Fan | | | |
| 15 | 1157158 | Screw | 37 | 2259092 | Cover, Condenser | | | |
| 16 | 2259307 | Condenser | 38 | 2307907 | Grommet, Edge | | | |
| 17 | 943447 | Grommet (4) | 39 | 2310251 | Service Cord | | | |
| 18 | 2310243 | Wire, Jumper | 41 | 549193 | Clamp, Cord | | | |
| 19 | 487522 | Screw | 42 | 2266802 | Switch, Power Disconnect | | | |
| 20 | 2155774 | Wire Tie | 44 | 486194 | Screw | | | |



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS

For Model: KSSC48FMS03
(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


LOWER UNIT AND TUBE PARTS

For Model: KSSC48FMS03
(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|-------------------------------------|
| 3 | 486194 | Screw |
| 4 | 2215508 | Bracket |
| 6 | 2259303 | Suction Tube |
| 8 | 2259304 | Tube, Connect (Drier/Restrictor) |
| 9 | 2320615 | Drain Pan Assy. |
| 10 | 2316683 | Cover, Wiring |
| 11 | 2316684 | Cover, Box |
| 13 | 2259354 | Tube, Discharge |
| 14 | 2188820 | Thermistor |
| 16 | 2306094 | Evaporator |
| 17 | 2306389 | Heater, Defrost |
| 18 | 1113048 | Clamp, Heater (2) |
| 19 | 2316794 | Seal, Return Air |
| 20 | 2220832 | Gasket, Evaporator |
| 21 | 4389107 | Wire Tie |
| 22 | 2215691 | Clip, Heat Exchanger |
| 23 | 9791833 | Clip |
| 26 | 2320554 | Support, Drain Pan |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Model: KSSC48FMS03
(Stainless Steel)**



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: KSSC48FMS03

(Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------------------|------------|----------|---|---|----------|--|
| 1 | 2221240 | Heater, Fill Tube | 16 | 488937 | Clamp Tube | 28 | 8533917 | Screw |
| 2 | 2259064 | Cover, Fill Tube Heater | 17 | 2313990 | Shut Off Arm | 29 | 2320597 | Shield, Valve |
| 3 | 2310136 | Wire Assembly, Ice maker | 18 | 2257538 | Cover | 30 | 489276 | Screw |
| 4 | 487539 | Screw | 19 | 2310108 | Wire Assembly, Fill Tube Heater | 31 | 488500 | Screw |
| 5 | 628379 | Clip, Fuse | 20 | 628228 | Mold & Heater (Also Order 542638 Silicone Grease) | 32 | 2310193 | Wire Assembly (Water Valve) |
| 6 | 2320654 | Tube, Filter Inlet | 21 | 626676 | Motor | 35 | 626678 | Module Assembly (Includes Items 21 & 41) |
| 7 | 2320672 | Water Inlet Tube Assembly | 22 | 628356 | Cup-Water Fill | 41 | 489136 | Screw (2) |
| 8 | 1106508 | Seal Gasket | 23 | 627843 | Ejector | 42 | 489464 | Screw |
| 9 | 2317912 | Tube, Filter Outlet | 24 | 2182124 | Ice Striper | 43 | 486194 | Screw |
| 10 | 2307650 | Valve, Solenoid | 25 | 2195914 | Support | 100 | 2320638 | Complete Ice maker Assembly |
| 11 | 489115 | Fastener, Snap-In | 26 | 2315522 | Retainer | Following Parts Not Illustrated (Optional Parts Only) | | |
| 12 | 2221070 | Clamp, Tube | 27 | | Thermostat (2) | | | |
| 13 | 2320559 | Support, Valve | | | Thermostat (Also Order 542639 Cement Alumilastic) | | | |
| 14 | 2221231 | Heat Shield | | | | | | 8537055 Cleaner, Stainless Steel |
| 15 | 2208136 | Clamp, Nylon Valve | | | | | | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST